



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki



Viewing /Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration

- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



powered by
screwturn wiki

Checking Extrusion Output Rates Without the Use of a Calculator

Modified on Monday, 02 February 2015 01:11 PM by [mpieler](#) Categorized as [Extrusion Hints](#) 
(10) » [Condensation](#) » [Extruding Amorphous Materials](#) » **[Checking Extrusion Output Rates Without the Use of a Calculator](#)**

Checking extrusion output rates without the use of a calculator
Vol. 27 #1, March 2000

Take an output rate for a 36 second interval. Weigh it on a scale in lbs or kg. Multiply this figure by 100. This will be the output rate of the extruder in lbs/hr or kg/hr. Report two or three times, to check output consistency. Average these output checks to calculate the average output rate.

- John Christiano, Davis-Standard

See also:

- [Output calculations](#)
- [Output rate check](#)
- [Output rates](#)
- [Extruder output](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .