



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

  »

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration

- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



Patience

Modified on Sunday, 01 February 2015 05:15 PM by [mpieler](#) Categorized as [Extrusion Hints](#) 

(10) » [Not Dry Enough](#) » [Barrel Heaters](#) » **Patience**

Patience

Vol. 18 #2, July 1991


When making process changes (screw speed, zone settings, etc.) allow four time constants to achieve a steady state prior to collecting data.

A typical 4 1/2" extruder requires 36 minutes.

See also:

- [Data collection 1](#)
- [Melt blocking](#)
- [Surging](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .