



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

  »

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration


- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



Gauge Systems

Modified on Sunday, 01 February 2015 05:27 PM by [mpieler](#) Categorized as [Extrusion Hints](#) 
(10) » [Computer Simulation](#) » [High Motor Amps](#) » [Gauge Systems](#)

Gauge Systems
Vol. 19 #1, Feb. 1992


Many of the sophisticated automatic gauging systems have a simple, but effective, calibration technique. (The technique must be well designed and very repeatable).

Be sure that it is being used on a regular basis. If you don't have a regular procedure, institute one.

See also:

- [Calibrate tachs](#)
- [Gauge variation](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .