



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

  [»](#)

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration


- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



Hopper Segregation

Modified on Sunday, 01 February 2015 10:08 PM by [mpieler](#) Categorized as [Extrusion Hints](#) 
(10) » [Die Lip Buildup](#) » [Cooling Water](#) » [Hopper Segregation](#)

Hopper Segregation
Vol.20 #3, Dec. 1993


If you have to mix feed materials in a single feed to the extruder, watch out for segregation of the materials in the feed hopper.

By running low levels of feed mix in the hopper, this segregation can be minimized.

See also:

- [Material clean out](#)
- [Hoppers](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .