



## Navigation



## Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

## Search the Wiki

  »

## Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

## Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

## Administration

- [Administration](#)
- [File Management](#)

## Brought to you by:

The SPE Extrusion Division  
Board of Directors



# Corona Treater Power

Modified on Sunday, 01 February 2015 10:54 PM by [mpieler](#) Categorized as [Extrusion Hints](#)   
(10) » [Liquid Injection](#) » [2 Machines](#) [1 Material](#) » [Corona Treater Power](#)

Corona treater power  
Vol. 22 #1, June 1995


When sizing the power supply for a corona treater, be sure to completely and accurately specify the polymer and all of the additives that it contains.

Certain additives, e.g. slip, require more power to achieve the same treat level than a barefoot resin requires.

See also:

- [Corona treatment](#)
- [Incoming power](#)
- [Power factor](#)
- [Sizing extruder drives](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .