



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki



Viewing /Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration

- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



powered by
screwturn wiki

Poor Stranding

Modified on Monday, 02 February 2015 12:13 AM by [mpieler](#) Categorized as [Extrusion Hints](#) 
(10) » [Screw Removal 4](#) » [PET Dryer Instrumentation](#) » **Poor Stranding**

Poor Stranding
Vol. 24 #2, Sept. 1997

Check die heaters. One may have failed.

- Paul Andersen, Werner & Pfleiderer

See also:

- [Strand cooling: good housekeeping](#)
- [Tidal waves](#)
- [Die heaters](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .