



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki



Viewing /Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration

- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



powered by
screwturn wiki

Purge

Modified on Monday, 02 February 2015 12:24 AM by [mpieler](#) Categorized as [Extrusion Hints](#) 

[\(10\)](#) » [Resin supplier](#) » [Melt Delivery](#) » **Purge**

Purge
Vol. 24 #3, Dec. 1997

a) Peanut shells work well as purge material.

b) Fractional melt flow HDPE

- Paul Andersen, Werner & Pfleiderer

See also:

- [Bridge breaker](#)
- [Feed throat configuration](#)
- [Oatmeal](#)
- [Purge 2](#)
- [Purge compound](#)
- [Screw cleaning 2](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .