



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration

- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division Board of Directors



# Film Mount

Modified on Monday, 02 February 2015 12:53 PM by [mpieler](#) Categorized as [Extrusion Hints](#) [\(10\)](#) » [Maximum Channel Depth for High Rate](#) » [Breaker Plate Maintenance](#) » [Film Mount](#)

Film Mount  
Vol. 26 #1, March 1999

An embroidery hoop makes close examination of film defects easy. Just clamp over film and pull out wrinkles. Film is held taut for microscopic examination with a hand held microscope.

- Ron Roller, Equistar Chemicals LP.

[Return to Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .