



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration

- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division Board of Directors



Condensation

Modified on Monday, 02 February 2015 01:08 PM by [mpieler](#) Categorized as [Extrusion Hints](#) (10) » [Cross Contamination \(Extrusion Hint\)](#) » [Pre-Drying Moisture Sensitive Polymer](#) » **Condensation**

Condensation
Vol. 27 #1, March 2000

Condensation can cause surface imperfections, "chicken tracks", craters, and if severe, can cause voids, blowouts and product/part breakdown. Condensation is normally a problem where the pellets are stored outside or in colder areas before using. Condensation on the pellets can also occur during periods of high humidity. Be sure material is properly dried to prevent this occurrence.

- Mark Sewak, LCI Corp.

See also:

- [Dehumidifying dryers](#)
- [Drying temperature](#)
- [Dryer inlet air](#)
- [Installing a dehumidifying drying system](#)
- [Pre-drying moisture sensitive polymer](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#)