



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

  [»](#)

Viewing /Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration

- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



Protect the Barrel

Modified on Monday, 02 February 2015 12:18 AM by [mpieler](#) Categorized as [Extrusion Hints](#) 
[\(10\)](#) » [Protect the Pump](#) » [Gear Pumps](#) » **[Protect the Barrel](#)**

Protect the Barrel
Vol. 24 #2, Sept. 1997

The exposed edge of the bimetallic liner of an extruder barrel can be easily damaged when inserting the screw.

Protect it with a ring made to fit the breaker plate recess/counter bore.

- Bill Kramer American Kuhne Corp.

- See also:
- [Early detection](#)
 - [Extra breaker plates](#)
 - [Worn barrel](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .