



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki


»

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration


- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



Monitor Heaters

Modified on Monday, 02 February 2015 12:41 PM by [mpieler](#) Categorized as [Extrusion Hints](#) 
(10) » [Turn the Screw by Hand](#) » [Twin Screw Extrusion](#) » **Monitor Heaters**

Monitor Heaters
Vol. 25 #2, Sept. 1998

Regular inspection of heaters and thermocouples will prevent start up difficulties by insuring that all equipment is effectively heated to the proper temperatures.


Monitoring this same equipment during operations will help troubleshoot processing problems by identifying cold zones.

- Bill Corcoran, Dupont Co.

See also:

- [Barrel heaters](#)
- [Melt temperature](#)
- [Seated TCs](#)
- [Temperature measurement 1](#)
- [Temperature measurement 2](#)
- [Thermocouple connections 1](#)
- [Thermocouple connections 2](#)
- [Troubleshooting with barrel zones](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .