



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki


»

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration


- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



Installing a Dehumidifying Drying System

Modified on Monday, 02 February 2015 12:46 PM by [mpieler](#) Categorized as [Extrusion Hints](#) 
(10) » [Die Drool](#) » [Twin Screw Extrusion 2](#) » [Installing a Dehumidifying Drying System](#)

Installing a dehumidifying drying system
Vol. 25 #3, Dec. 1998

When installing a dehumidifying drying system, the drying hopper should always be placed directly above the extruder feed throat, if possible.


The dried resin can then be discharged from the drying hopper directly into the extruder throat without exposure to the ambient air, thus eliminating the potential for moisture regain.

- Pete Stoughton, Conair

See also:

- [Condensation](#)
- [Cool dryer return air](#)
- [Closed loop dryer](#)
- [Dryer inlet air](#)
- [PET dryer](#)
- [PET dryer instrumentation](#)
- [Pre-drying moisture sensitive polymer](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .