



Mitsui Plastics Inc.

New Catalyst Neutralizer Polymer Protector Additive for Polyethylene

1

Presented to the 2019 SPE Polyolefins Conference, Houston, TX

History of acid scavengers in Polyolefins:

- First Generation 1955 + : For over 60 years Metallic Stearates and oxides have been used in PE. Originally designed for 1-3rd generation non-magnesium supported. Poor polyolefin oxidative stability requiring higher AO levels. Lewis Acid problem.
- Second Generation 1984+; Hydrotalcite used in PP and solution process LLDPE only. Improved oxidative stability. Color issues with certain catalysts and AO's from high pH.
- Third Generation 2017+; Mitsui M-Series catalyst neutralizers and polymer protectors for 4th -6th generation catalysts. Lower color improved and highest oxidative stability allowing AO reduction.

Mitsui M-Series Catalyst Neutralizer Chemistry comparisons

Mitsui Plastics Inc.					Metallic Stearates, Oxides
Various CAS numbers		FDA	EU 10/2011 listed		
Additive number:	3L	7L	37L	70P, 737LP	CaSt, ZnSt, ZnO
North America Supply	Developmental quantities	Developmental quantities	Developmental quantities	Developmental quantities	USA, EU, Asia
Particle size range in microns	0.5-0.8	0.5-0.8	0.5-0.8	0.5-0.8	10-35
Stoichiometry Formulation	Trade Secret	Trade Secret	Trade Secret	Trade Secret	(C ₁₇ H ₃₅ COO) ₂ Ca (C ₁₇ H ₃₅ COO) ₂ Zn ZnO
Acid mechanism:	Catalyst Neutralizer Polymer protector	Catalyst Neutralizer Polymer protector	Catalyst Neutralizer Polymer protector	Catalyst Neutralizer Polymer protector	Acid Scavenger
Catalyst design:	4 th , 5 th 6 th generation	4 th , 5 th 6 th generation	4 th , 5 th 6 th generation	4 th , 5 th 6 th generation	1 st and 2 nd generaton




4


Mitsui Plastics

catalyst neutralizer efficiency


Catalyst acid neutralizer efficiency



Acid neutralized efficiency per similar volume




Acid produced by polyolefin type Mitsui neutralizer effective all catalysts and all densities





M-Series catalyst neutralizer suggestions:

			SUGGESTIONS		ppm of acid from TiCl4	Commercial Examples
Ziegler-Natta Catalyzed Polyolefins	g-cat/xxxxg Polyolefin	ppm Ti in polyolefin	phenolic AO ppm / phosphite AO ppm	Ppm of Mitsui M-Series	HCL = ppm Ti x (141.6/47.9 (ppm/mole))	
		1gTiCl4 = 25.27% Ti				1 ppm Ti = 4 ppm HCL 1 ppm Mg = 3ppm HCL**
Polyethylene	1g-cat/50,500g 1kg-cat/50 tons PE	5	500/1000	600	35	0.934-0.920LLDPE film grades
	1g-cat/25,200g 1kg-cat/25.2 tons PE	10	375/750 =25% less AO	800	70	0.920-0.910 LLDPE film grades
	1g-cat/12,600g 1kg-cat/12.6 tons PE	20-25	350/700 =30% less AO	1,000	140-175	0.880-0.909 Plastomers Bi-modal HDPE pipe and film grades
	1g-cat/8,400g 1kg-cat/8.4 tons PE	30	350/700 =30% less AO	1000	210	bi-modal HDPE (Mitsui CX).



- * ppm XRxL needed to neutralize catalyst acid, stabilized anti-oxidants and protect the polymer from degradation. **20x the HCL concentration.**
- ** HCL from MgCl2 catalyst support which is 2.89 ppm HCL / 1ppm Mg. So, **1ppm Ti + 1 ppm Mg = 7 ppm HCL.**

How does Mitsui's M-Series neutralizer work?

- ▶ **Proprietary** blend designed for:
 - ▶ 4th – 6th generation TiCl₄-MgCl₂ catalysts.
 - ▶ polyolefin density ranges 0.640 – 0.965
- ▶ Color correction chemistry, Balanced pH and surface area = lowest color.
 - ▶ Performs excellent with antioxidants per pellet, LAB, YI.
- ▶ H/E lubricants reduces shear and heat stress
 - ▶ Improved polymer stability per FTIR
 - ▶ Improves antioxidant efficiency per OIT, HPLC



10

Polyethylene results

Mitsui ZRxL Development in HDPE pipe and LLDPE film resins

Problems with metallic stearates and oxides in Polyethylene

1. Acid scavenging chemistry:



2. CaCl_2 is a **corrosive "Lewis acids"** (ref.1)

- ▶ Lewis acid examples : TiCl_4 , ZrCl_4 , ZnCl_2 , CaCl_2 , NaCl


- ▶ Lewis acids destroy antioxidants and hindered amines (HALS).

3. **Stearic acid** has a 114c flash point so carbonizes which forms black specs, die smoke and plate out.



Problems with metallic stearates and oxides **at molders**

- **Black specs**
 - Molded from 1st extruder pass of 0.906g/cc density LLDPE.



Polyethylene formulations

13

- **Bi-Modal HDPE** 0.03 MI, **0.949** g/cc density
 - Extrusion at 90 RPM, **Tm 190c ***
 - Antioxidants: 500 ppm AO 1010 + 500 ppm AO 168
 - **MPI 7L development vs Controls: CaSt, HT, HT-2**

- **C6-LLDPE** 0.50 MI, **0.917** g/cc density
 - Extrusion at 90 RPM, **Tm 190c ***
 - Antioxidants: 500 ppm AO 1010 + 500 ppm AO 168
 - **MPI 3L development vs Controls: CaSt, ZnSt, ZnO, HT-2**

- **C6-LLDPE** 0.50 MI, **0.917** g/cc density
 - Extrusion at 30 RPM , **Tm 250c under N2 ****
 - Antioxidants: 500 ppm AO 1010 +1,000 ppm AO 168
 - **MPI 737P development vs HT, CaSt**

New Fall 2018 developments with 25-30% AO reduction

Polyethylene formulations

- **C6-LLDPE** 0.50 MI, **0.906** g/cc density
 - Extrusion at 30 RPM, **Tm 250 c** * *
 - Antioxidants: 800 ppm AO 76 + 1400 ppm Weston 705T.
 - **MPI 3L and 37L development vs CaSt**

* **Extruder details:** 3/4in 20mm SSE with 33:1 L/D with 2 mixing zones Z1 =170 C, Z2 =190 C, Z3 =190 C, **Die 190 C, screw RPM =90**

** **Extruder details:** 3/4in 20mm SSE with 33:1 L/D with 2 mixing zones **Die 250c, screw RPM = 30**, Rate 1.5-3.0 kg/hour.

Molding details: 30 Ton hydraulic injection press (SPEC capable, ASTM, ISO, test bars, 3"x3" GM texture Plaques, machined-in notched Izod bars.) 390/450/450 Deg. F, 2500psi 30 seconds cooling time.

HDPE data:

Bimodal pipe grade 0.947 g/cc

Blow molding grade 0.950 g/cc

M-Series 7L development vs calcium stearate and Hydrotalcite

Extrusion at 90 RPM, **Tm 190c**


Antioxidants: 500 ppm AO 1010 + 500 ppm AO 168

M7L protects antioxidants

16


OIT @200c minutes

MPI 7L 32% less HDPE oxidation vs HT and 56% less than Calcium stearate






M7L 31% - 80% more AO retained




M7L reduces extruder pressure in HDPE

18




M7L lowest color in Bi-modal HDPE pipe grade

19




M7L 40-60% improvement in the quality of HDPE molded parts



M37L and M3L shows no color oxidation in HDPE

21



C6-LLDPE 0.917g/cc

MPI 7L and 37L development

vs CaSt, ZnSt, ZnO and Hydrotalcite


Extrusion at 90 RPM, **Tm 190c**

Antioxidants: 500 ppm AO 1010 + 500 ppm AO 168

M7L stable multi-pass MI

0.917 C6-LLDPE MI 190c/10kg

23




M3L and M7L low color LLDPE

24

YI from molded tensile bars 1st extruder pass, 3rd and 5th. 70c 6 week oven aging from 3rd pass.

Extruder details: 3/4in 20mm SSE 33:1 L/D


with Z1 =170 C, Z2 =190 C, Z3 =190 C, Die 190 C, screw RPM =90, Screw: mixing head



ZnO blue shade pigment color change is very high

M3L 30% lower extruder pressure in LLDPE

25




NOTES: ZnO 1st extrusion black die drool and by 5th black powder residue



M3L and M7L 60-75% improvement in quality in LLDPE

Polymer Performance Quality Quotient = Higher number better quality
 HDPE 1% mod / Std. Dev
 LLDPE TS / Std. Dev

Red → Part to part Std. Dev. Lower number better quality



C6-LLDPE 0.917g/cc

New M-Series M737LP developments NOV 2018
vs calcium stearate and Hydrotalcite

1, 3, 5 Extrusion at 30 RPM, Tm 250c under N2


Antioxidants: 500 ppm AO 1010 +1,000 ppm AO 168

27




M737P no yellow 1-5 extruder passes

Pellet YI yellowness Index. AO only YI = 5.6




M737P even with 30% less AO more stable than the Calcium Stearate Control

MFR 230c, 2.16kg AO only 8.33g/10min.



M737P high oxidative stability even with 30% less antioxidants

30




C6-LLDPE 0.906 g/cc

Mitsui's M-Series M3L and M37L compared to Calcium Stearate

Extrusion at 30 RPM, **Tm 250 c**


Antioxidants: 800 ppm AO 76 + 1400 ppm Weston 705T.

M3L and M37L show improved MI stability in LLDPE plastomer



Mitsui 3L and 37L show excellent low YI color in LLDPE plastomer

33




FTIR oxidation values vs YI raw data

FTIR raw data	1/cm	M3L 1st	M3L 5th	M37L1st	M37L5th	CaSt 1st	CaSt 5th
Corr Area							
CH2 group	720	2.319	2.865	4.223	1.28	3.71	3.627
CH2 group	730	1.246	1.085	1.124	1.953	1.354	0.139
C-C bond	1465		0.842	0.481	1.781	0.946	1.301
C=O	1720				0.062	0.137	0.277
C=O	1740	0	0.039	0.193	0.549	0.356	0.369
OH	3603	1.528	2.013	1.306	3.468	1.883	1.505

Ratio C=C/C2 1740/730 0 0.035945 0.171708 0.281106 0.262925 2.654676


Ratio C=O/C2 1720/730 0 0 0 0.031746 0.101182 1.992806

Pellet YI -8.97 -5.35 -9.34 -4.78 -6.12 8.33





M Series no PE oxidation and lowest color.
CaSt high oxidation even with low color.



M-Series recycle improvements + odor reduction

- Performance:
 1. 45-145 % increased time to oxidize.
(DSC OIT oxygen induction time at 200c.)
 2. Antioxidant is preserved per LC analysis:
 - 30% increase 1st extruder pass
 - 60-80% increase 5th extruder pass
 3. Average 50-90% less degradation
- per FTIR. (C=O carbonyl @1720-1740-cm / C2 % @ 730-cm)

- Value: average 50-90% increase in recyclability and odor reduction due to antioxidant preservation and reduced polymer oxidation.

Mitsui Plastics Inc. M-Series for Polyethylene

Summary

- ▶ Market:
 - ▶ Effective in all 4th – 6th generation ZN catalysts.
 - ▶ Replace 800 -1,000 ppm metallic stearate or metallic oxide with equal ppm of M-Series.
- ▶ Improved Quality:
 - ▶ 45-145 % increased time to oxidize. (OIT DSC oxygen induction time at 200c.)
 - ▶ 30% increase in antioxidant retention - per HPLC 1st extruder pass. **60-80% by 5th pass.**
 - ▶ 40-50% reduction in film gels – per customer
 - ▶ Average 50-90% less degradation - per FTIR. (C=O carbonyl @1720-1740-cm / C2 % 730-cm)
- ▶ Improved: Performance:

20-30% reduction in extruder pressure. Possible, lower melt fracture.

40-60% increase in LLDPE tensile strength and HDPE Flex. Mod.

40-75 % reduction in part to part Std. Dev.
- ▶ Savings + improved quality and performance – up to \$500,000 / each 1B lbs.

M-Series powder and pellet forms

Made in Germany (pellets in mm)



Mitsui Plastics Inc. presentation to SPE Polyolefins Conference

Made in USA



Feb 24-27, 2019

For further information and samples: Reference:

- ▶ Please contact:
 - ▶ Don Beuke – Mitsui Plastics Inc.
 - ▶ 918-914-2947
 - ▶ D.Beuke@mitsui.com
- ▶ REF 1. Mechanism of Lewis Acid Metallic stearates and oxides
 - ▶ ZnCl₂ CaCl₂ are Lewis acids because it can accept an electron pair from a Lewis base like OH- Tert-butyl phenolic antioxidant.
 - ▶ A Lewis acid is a molecule that can accept an electron pair and a Lewis base is a molecule that can donate an electron pair. When a Lewis base combines with a Lewis acid an adduct is formed with a coordinate covalent bond.
 - ▶ i.e. $\text{CaCl}_2 + 2 (\text{OH- T-butyl phenol}) \longrightarrow \text{Ca(OH)}_2 + 2\text{Cl} + 2\text{H}_2\text{O} \rightarrow 4\text{HCl} + \text{O}_2$

Thank you

SPE Polyolefins Conference – Dr. Thoi Ho Additives Chair.

Our polyolefin customers – you know who you are!

Mitsui Plastics Inc. USA – financial support (many RINGI's)

Amazing plastics laboratories: Nobukatsu Shigi – Japan, Dr. Amit Dharia – USA,

Mitsui Plastics Inc. - Disclaimer

- ▶ *The values and information represented herein are typical and should not be considered to represent any specification. Mitsui Plastics, Inc. ("Mitsui") does not guarantee the reproducibility of the data represented herein in customer's own or contracted testing facility. Mitsui makes no warranty, express or implied, regarding merchantability or fitness for a particular purpose. Freedom from the infringement of a patent of Mitsui or any other party is not to be inferred. Customer is solely responsible to verify the suitability of the material for their intended use. In no case shall Mitsui have any liability to any person in respect of any loss, claim, damages, costs or liability arising from reliance on any information contained in this report or use of this report.*