

# Accelerated Slow Crack Growth Resistance Tests For Characterization of High- Performance Bimodal HDPE Pipe Materials

---

Univation Technologies /  
The Dow Chemical Company

SPE International Polyolefins Conference  
Houston, TX  
February 24-27, 2019

Cliff Mure  
Dane Chang  
Rujul Mehta  
Siddharth Athreya



# Topics

---

- Introduction
- Accelerated tests for SCGR
- Bimodal Polymer Structure
- Results of accelerated tests
- Conclusions

## Univation Technologies – Global Licensor Leader of UNIPOL™ PE Technology



**171**

Licensed reactor lines in  
**28** countries



**51**

**Millions tonnes annually**  
global licensed capacity



**28**

**Operating lines  $\geq 400$  kTA**  
capacities – proven large  
capacity leader



**47**

**Reactor lines in design**  
or under construction

## Univation Technologies – World's Leading PE Technology



### BROADEST PRODUCT CAPABILITY

- Unparalleled single-reactor product flexibility
- Diversified PE portfolio
- Full density HD / LLD product coverage
- Differentiated products
- Large-volume applications



### WORLD'S LEADING PE TECHNOLOGY

- Streamlined design
- Largest proven single-line capacity: 650 kTA
- Lowest CAPEX: 95 – 120 million USD *lower* investment than multi-reactor / multi-loop processes
- Maximizes return on your overall investment
- Enables capturing new opportunities



### SERVICES FOR LONG-TERM SUCCESS

- Comprehensive project support
  - Engineering
  - Construction
  - Commissioning
  - Start-up
- Exceptional technology transfer
- PREMIER™ Products and Services
  - Takes performance to the next level



### COMMITTED TO INNOVATION

- UNIPOL™ PE Technology transformed the industry – continues today
- Recognized PE industry leader
- Track-record of innovation
- Full-range R&D programs
  - Products
  - Process
  - Catalysts
  - Process control







## High-Performance HDPE Pipe Materials

---

- PE100 → PE100 RC: NPT (ISO 13479) > 1 year
- PE4710: PENT (ASTM F1473) >> 10,000 hours
- Material suppliers have a need for faster evaluation of SCGR of pipe materials for new product development
- Batch release to ensure production quality

# Accelerated Tests


- New methods are allowing characterization of SCGR in times ranging from 1 day to weeks
- Strain hardening modulus (SHM), ISO 18488: data from tensile testing
- Accelerated full notch creep test (aFNCT), ISO 16770:
- Cracked round bar (CRB), ISO 18489: Fatigue crack growth (FCG) predicts creep crack growth (CCG).
- Accelerated point load (PLT+): Pipe with point loading accelerated with surfactant solution.



# Bimodal HDPE


- How do we make bimodal HDPE?
- Reactor configurations – 1, 2, 3
- Catalyst type
- Reaction environment – T, gas composition
- Post-reactor treatment – additives, compounding, etc.

Many factors determine the resulting bimodal polymer




# Polymer Structure Effects on SCGR

- Tie molecule structure for SCGR performance
- Polymer variables to affect tie molecules
- Length of chains – MW, MWD
- Comonomer – Type, amount and placement



Semi-crystalline structure



# Effects of Improved Comonomer Distribution

- The materials were characterized by SHM, aFNCT, and PLT+ (Hessel)
- The samples with improved comonomer distribution exhibits higher performance in each of the tests – SHM, aFNCT, CRB, and PLT
- Accelerated version of PLT was used for the pipe test
- SHM is useful for batch release.

Description	SDH Modulus	aFNCT @ 5 MPa hrs	CRB cycles at Ds=12.5 MPa	PLT+ hrs (accelerated version)
PE100 Control	58	249	$1.50 \times 10^6$	429
Improved Comonomer distribution	61	473	$1.57 \times 10^6$	841





Figure 1: Point loaded location of sample B5






# Design of Experiment

- A DOE was conducted to study effects of bimodal PE design variables – HMW density and HLMI, split (% HMW)
- The density and HLMI of the HMW component are strong drivers of SCGR
- Relatively narrow range of density
- The SCGR performance was measured by PENT and SHM

Sample #	Overall Product Density	HMW density	HMW I21	Split ratio (%)	Strain Hardening modulus (Mpa)	PENT Failure time at 2.4MPa 80C (hrs)
Sample 1	0.949	--	-	-	63	15000
Sample 2	0.952	++	+	+	37	88
Sample 3	0.952	+	+	+	41	160
Sample 4	0.952	0	0	+	47	640
Sample 5	0.952	0	0	-	36	1120
Sample 6	0.951	0	0	-	50	1630
Sample 7	0.951	--	-	-	58	8200
Sample 8	0.949	--	-	0		17000
Sample 9	0.954	++	-	0	38	100


## PENT vs. SHM

- The PENT-SHM correlation generally looks good.
- One possible outlier. This will be investigated further.




## NPT vs. SHM

- The NPT performance is required for ISO PE100 water and gas pipe
- Higher-performing PE100 RC materials exhibit failure times of > 1 year.
- SHM exhibits a good correlation with NPT



## aFNCT vs. SHM

- aFNCT is used to characterize PE100 RC materials. Failure times are relatively long for batch release testing
- Materials used include C<sub>6</sub> and C<sub>4</sub> copolymers and different polymerization processes
- aFNCT conditions: 2% Dehyton, 90°C, 5.0 MPa
- Good agreement between SHM and aFNCT



## Conclusions

---

- New generations of high-performance PE100 and PE4710 type materials present challenges for testing developmental products and for production QA testing
- SCGR has been improved by lowering the density of the HMW component and optimizing the distribution of comonomer across the MWD. SCGR of these materials by traditional tests exceeds 1 year
- The SHM showed good correlation with NPT, aFNCT and PENT
- SHM, with the shortest time required to achieve results, is especially well-suited for batch release testing



# Thank You!

## Questions?





Proven Designs. Limitless Possibilities.

**Cliff Mure**

cmure@Univation.com

Visit us at [www.univation.dow.com](http://www.univation.dow.com)

## Trademarks

---

Univation Technologies, LLC is the world leader in licensing gas-phase polyethylene technology and selling related catalysts, services, and products. UNIVATION, XCAT, PRODIGY, PREMIER, ACCLAIM, stylized “Univation Technologies,” and the stylized “U” are registered trademarks (Reg. U.S. Pat. and Tm. Off. and other countries) of Univation Technologies. UNIPOL and UCAT are trademarks of The Dow Chemical Company (“Dow”) or an affiliated company of Dow, licensed for use to Univation Technologies.

© 2019 Univation Technologies, LLC. All Rights Reserved